



PRODUCT INFORMATION

HARDWOOD REPAIR KIT

RAPID SETTING, TWO-COMPONENT, POLYURETHANE ADHESIVE

PRODUCT DESCRIPTION

This rapid setting, two-component polyurethane adhesive, is used to replace floor boards, repair hollow spots, and to install thresholds and moldings. The adhesive has extremely high bond strength and flexibility, making it the perfect choice when bonding wood to wood, or wood to concrete. After the adhesive flows through the static mixer, the two components are combined and they begin to set up in 10 minutes. Full cure is achieved after 30 minutes. This adhesive system is highly water resistant and will outperform epoxy, white and yellow wood glues.

FEATURES & BENEFITS

- Contains no water
- Fully cured in 30 minutes
- Flows easily
- Remains flexible
- Will not become brittle
- Exceptional bond to wood and concrete
- Easy to use

DIRECTIONS

Hollow Spot Repair

1. Open foil packet and remove the adhesive, static mixer and 1/16 needle.
2. Place the adhesive into the dispensing gun.
3. Remove the plastic cap and rubber plug from the adhesive cartridge.
4. Insert the wide end of static mixer into the adhesive cartridge and twist 1/4 turn.
5. Place the slip-on-needle onto the other end of the static mixer.
6. Locate the center of the hollow spot.
7. Find an area close to the center that has dark grain.
8. Place a strip of blue tape over the dark grain.
9. Drill through the blue tape into the dark grain with a 1/8" drill bit.
10. Insert the needle into the hole and squeeze the handle of the dispensing gun.
11. When the hollow spot is completely filled, remove the blue tape and wipe up any excess adhesive.
12. Use either colored wood putty or touch up crayon to "blend in" the repair.



Board Replacement

1. Remove the floor board(s) in accordance with NWFA instructions for floor board replacement.
2. Place the adhesive into the dispensing gun.
3. Remove the plastic cap and rubber plug from the adhesive cartridge
4. Insert the wide end of the static mixer into the adhesive cartridge and twist 1/4 turn.
5. Using a "S" pattern, apply a bead of adhesive on the substrate.
6. Place a bead of adhesive on the tongue of the replacement board.
7. Insert the replacement board into the floor and press own firmly.
8. Let the adhesive cure 30 minutes before exposing the area to heavy foot traffic or sanding equipment.



PACKAGING

Hdwd Repair Kit (B11130) - 80 kits per case

Each foil packet contains:

- 50 ml of 100% urethane adhesive
- 1 static mixer
- 1/16" needle

Accessories (can be purchased separately)

- Adhesive 4:1 dispensing gun (Item# B11133)
- 4:1 ratio replacement plungers (Item# B11132)
- Nozzle kit (Item# B11135)
 - Ten static mixers
 - Ten 1/16" needle



Middleton, MA 01949

1-800-7/BOSTIK

1-800-726-7845

www.bostik-us.com

PLANT LOCATIONS

Conyers, GA 30207

Temecula, CA 92590



LIMITED WARRANTY

All statements, technical information, and recommendations set forth herein, are based on tests which Bostik believes to be reliable. However, Bostik does not guarantee their accuracy or completeness. The buyer should conduct his/her own tests of this product before use to determine proper preparation technique and suitability for proposed application. Any sale of this product shall be on terms and conditions set forth on Bostik's order acknowledgement. Bostik warrants that the product conforms with Bostik's written specifications, and is free from defects. BOSTIK DISCLAIMS ALL OTHER WARRANTIES, EXPRESS OR IMPLIED, INCLUDING THE WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. THE BUYER'S SOLE REMEDY FOR NONCOMPLIANCE WITH THIS WARRANTY SHALL BE FOR THE REPLACEMENT OF THE PRODUCT OR REFUND OF THE BUYER'S PURCHASE PRICE. IN NO CASE WILL BOSTIK BE LIABLE FOR DIRECT, CONSEQUENTIAL, ECONOMIC OR OTHER DAMAGES.

